



4 PORTS POE SWITCH

GE-P4002-UT



GE-P4002-UT

4 Ports PoE Switch



Shop No. 338/1, G.M. Complex, Ganthipuram Sixth St,
Gandipuram, Coimbatore, Tamil Nadu 641012



+0 98433 59251



nidhienterprisesbbe@gmail.com
www.grandeye.net

Installation steps

- ❖ Use a network cable connect equipment uplink port and NVR or computer;
- ❖ Connect power adapter ;
- ❖ Check if the installation is correct, equipment is in good condition, the connection is stable, then power on for system;
- ❖ Ensure the Ethernet equipment with power on can work properly.

Trouble shooting

Please follow the steps if the equipment has trouble.

- ❖ Make sure the equipment is installed according to the manufactures installation guide.
- ❖ Confirm RJ45 cable order meets EIA/TIA568A or 568B standard.
- ❖ Every PoE port can provide PoE equipment maximum power less than 30W, please do not connect the PoE equipment with power over 30W.
- ❖ Replace the equipment with a proper functioning 4 ports PoE Ethernet Switch to check if the equipment is damaged
- ❖ Please contact your vendor if trouble still exists.

Plug Producing Method

Instruments to be used: wire crimper, network tester. Wire sequence of RJ45 plug should conform with EIA/TIA568A or 568B.

- ❖ Please remove 2cm long the insulating layer, and bare 4 pairs UTP cable;
- ❖ Separate the 4 pairs UTP cable and straighten them;
- ❖ Line up the 8 pieces of cables per EIA/TIA 568A or 568B;
- ❖ Cut out 1.5 cm cable wrap and leave the bare wire;
- ❖ Plug 8 cables into RJ45 plug, make sure each cable is in each pin;
- ❖ Use the wire crimper to crimp it;
- ❖ Repeat above 5 steps to make the another end;
- ❖ Use network tester to test the cable if it works.

Pin	Color
1	white/green
2	green
3	white/orange
4	blue
5	white/blue
6	orange
7	white/brown
8	brown



EIA/TIA 568A

Pin	Color
1	white/orange
2	orange
3	white/green
4	blue
5	white/blue
6	green
7	white/brown
8	brown



EIA/TIA 568B